

# MC-4 On the wall Media Cabinets



**WG** *Wood Products*

- We have provided you with nails for your backer board, but it is not necessary to nail it into place. The backer board fits inside a very narrow lip and it has been cut to fit tightly. You should be able to simply push it down into place, then screw your cabinet to the wall.
- There are four pocket holes inside the cabinet that are used to mount the cabinet to the wall. Two are in the top and two are in the bottom.
- For 7 ½" deep cabinets, Locate the studs on your wall and be certain that you are screwing AT LEAST two of the screws (one at the top and one at the bottom) into a stud. Other depth cabinets do not require studs but it is better if you can do it.
- 2 ½" screws have been provided for you to attach your media cabinet to the wall.

### Instructions for mounting your hinges

1. Locate the pre-marked holes on both the cabinet and the door.  
*These are meant as a GUIDE only. Actual hinge holes may differ slightly.*
2. It is easiest to mount the hinge on the CABINET first. Mount the hinge with the screw in the CENTER of the holes. (See Photo A). That way, you will have some minor adjustment of the door up and down should you need or desire it.
3. Last, mount the hinges onto the door starting at the top. You may need someone to help you with this step so that they can hold the door in place while you are inserting the screws.
4. If your door requires a minor adjustment up or down, simply loosen the screws on the CABINET side of the hinge and adjust it, then re-tighten them.
5. Door bumpers or felt pads have been provided to keep your door from hitting the cabinet when shut. (See Photo B)





**3 easy steps to  
installing  
optional  
concealed hinges**

1. Set your cabinet face up on a flat surface. Now attach the concealed hinges to the inside of the cabinet so that the edge of the hinge is against the edge of the cabinet's frame. Generally, mounting the hinges about 1" from the top and bottom of the cabinet is acceptable, though it is not a hard and fast rule. The "gap" between the edge of the hinge and the edge of the cabinet indicated by the yellow arrow above should be nonexistent. You will only need to install two screws at this time. Hinges are usually marked with DOOR on the door side of the hinge.
2. Lay the door on top of the cabinet and position it so that it has an even amount of overhang all the way around the opening of the cabinet. Our doors are designed with 1/2" of coverage all the way around, so that overhang should be about 1/2" all the way around. An easy way to obtain this is to use [post-it notes](#). Simply mark 1/2" from the top of a post it note and then stick one post-it note against each edge of the door. That way, it will be easier to line the door up in step 3. **DO NOT USE MASKING TAPE OR ANY OTHER TYPE OF TAPE AS IT WILL LIKELY DAMAGE YOUR FINISH. We will not be responsible for damage to the finish from failure to follow instructions.**
3. Now turn the cabinet upside down on top of the door and line it up to your marks on the post it notes. This method should ensure you have 1/2" overhang all the way around the opening and your hinge will now be in the correct position to screw it to the back of the door. Screw two screws into the hinges on the door side. Flip the cabinet back over and carefully check for correct opening and positioning of the door. When you are satisfied with the door's movement and position, place the remaining screws in the hinges.

**BE VERY CAREFUL!** On doors, be sure that you don't put a screw into a place on the door where there is no frame (such as a glass or mirror panel door, or if the screw could potentially go through the routed edge of a door and come out on the front side! Also, be careful not to place screws on the joint of a door as it could potentially split the door joint apart. This is why most doors will only need TWO screws per hinge.