



# On-the-wall Toilet Paper Holder

For Models TP-13



**WG** *Wood Products*

## Instructions:

- The easiest way to a nice tight fit is to mark the screws before starting. Place one screw into the keyhole slot and slide it over as far as it will go. While pulling the screw tight against the inside of the keyhole, place a mark on the screw using something like liquid paper or paint of some kind. This mark represents the point at which you will stop screwing the screws into the wall for a nice tight fit.
- Follow the same procedure to mark all the remaining screws.
- Use the template below to mark your wall for screw locations. Drive the screws into your wall until your marks
- Insert your shelf onto the screws and slide it to the left. It will lock into place.
- If your screws are too tight, the shelf won't slide, so loosen them  $\frac{1}{4}$  turn at a time until they work properly.
- If your screws are too loose, the shelf won't sit flush against the wall, so tighten them  $\frac{1}{4}$  turn at a time until the shelf slides on tightly.

